

NON PENN MOUNT

CONTENTS: 1 Mast
1 Tripod
1 Frame
--2 Long rails
--4 Short rails

Hardware Baggie:
--1 Long carriage bolt
--11 short carriage bolts
--12 flat washers
--12 locknuts

- ◆ ASSEMBLE THE OUTER FRAME BY LAYING THE TWO LONG RAILS PARALLEL TO EACH (APPROXIMATELY 30" APART). INSERT A SHORT CARRIAGE BOLT FROM THE BOTTOM AT EACH RAIL END, POINTING SKYWARD. (4 TOTAL)
- ◆ CONNECT THE 2 LONG RAILS BY PLACING 2 SHORT RAILS ON TOP OF THE 4 PROTRUDING BOLTS TO FORM A RECTANGLE.
*** MAKE SURE THE SQUARE HOLES IN THE SHORT RAIL "SIDES" ARE DIRECTLY OPPOSITE EACH OTHER.*** PLACE A WASHER AND NUT ON EACH OF THE FOUR BOLTS AND FINGER TIGHTEN.
- ◆ POSITION THE TRIPOD *WITHIN* THE 4- SIDED FRAME. SECURE THE 3 LEGS TO THE INSIDE OF THE FRAME BY INSERTING 3 SHORT BOLTS, FROM THE INSIDE AND PLACING THE WASHER AND NUT ON THE OUTSIDE OF THE FRAME.
- ◆ DROP THE BOTTOM OF THE MAST (THE END WITH THE HOLE) THRU THE TOP OF THE TRIPOD COLLAR.
- ◆ NOW PLACE THE REMAINING 2 SHORT RAILS PAPPALLEL TO EACH OTHER, SEPARATED BY THE BOTTOM OF THE MAST. ALIGN THE HOLE AT THE BOTTOM OF THE MAST, WITH THE 2 SQUARE HOLES IN THE SHORT RAIL SIDES. INSERT THE LONG BOLT AND CONNECT THE RAILS TO THE MAST.
- ◆ FROM THE UNDERSIDE OF THE FRAME, INSERT THE 4 REMAINING SHORT BOLTS UPWARD AND CONNECT THE INNER SHORT RAILS TO THE FRAME.
- ◆ TIGHTEN ALL NUTS TO SECURE.


9487 King Air Court Suite C Ashland, VA 23005
www.3starinc.com | sales@3starinc.com | Tel: (804) 550-7202