



**ANCHOR BOLT SETTING PROCEDURE**  
 SET TEMPLATE OVER ANCHOR BOLTS BEFORE POURING CONCRETE.  
 CHECK REQUIRED ANCHOR BOLT PROJECTION TO MATCH FOUNDATION DRAWING. AFTER CONCRETE HAS SET, REMOVE TEMPLATE. SET TOWER IN PLACE, USING LEVELING NUTS TO PLUMB TOWER. FINALLY, GROUT UNDER FLANGE PLATES AND PROVIDE FOR DRAINAGE ON ALL THREE TOWER LEGS.

NOTE: HOLES FOR ANCHOR BOLTS IN WOODEN BOARDS MUST BE SAME DIAMETER AS THE ANCHOR BOLTS BEING USED.

FILE NO.		Standard-SSV	
REVISIONS			
REV.	DESCRIPTION	DWN	CHK
4	REWORK INTO AUTOCAD FORMAT	NBS	JOM
DATE: 3/30/2007		NBS	HA

DWG REFERENCE	

**ROHN**  
 PRODUCTS  
 6718 WEST PLANK ROAD  
 PEORIA, IL 61604  
 TOLL FREE 800-272-ROHN

THIS DRAWING IS THE PROPERTY OF ROHN. IT IS NOT TO BE REPRODUCED, COPIED OR TRACKED IN WHOLE OR IN PART WITHOUT OUR WRITTEN CONSENT.

ANCHOR BOLT LAYOUT PROCEDURE FOR SSV TOWERS			
DWN:	OH	CHK'D:	TWS
ENGR:	RDM	DATE:	OCT/11/1971
DRAWING NO.:	C711017		REV.:
			4